



alcatel

PIXI4


QUICK START GUIDE



4034X
4034D
4034F




① Removing or installing the back cover.



② Installing or removing the battery.

③ Charging the battery.



④ Inserting or removing the SIM card.

⑤ Installing or removing the microSD card.

User guide and FAQ are available online
www.alcatel-mobile.com

* This phone doesn't support SIM card or SD card removal without turning off the device.

SAVE
PAPER
SAVE
TREES

PLEASE CONSIDER THE
ENVIRONMENT BEFORE PRINTING